

Shooter's Emporium, Inc.

606 SE 162nd Ave.

Portland, OR 97233

Toll Free: 1-800-323-7940 Phone: 503-257-0524 Fax: 503-922-1556
email: stocks@shootersemporium.net web: www.shootersemporium.net

Care & Maintenance

To further your appreciation and enjoyment for this product we have provided a few directions on how to adjust and maintain your SoftTouch to enhance your shooting pleasure and ability. SoftTouch Pat# 4,663,877.

- **The comb height** is easily adjusted by loosening the two screws in the side of the comb with the provided Allen Keys, raise/lower to desired height, and re-tighten. Longer posts are available should you need to adjust for a high rib barrel.
- **If your system includes the "Four Way"** adjustable comb you may adjust the comb height as above. To adjust left/right remove the comb then loosen the screws in the posts with the provided Allen Keys and move the posts sideways for desired offset. Re-Tighten post screws, then replace the comb and re-tighten
- **If your system is the "Supreme"**, in addition to the above, you may adjust the pressure required to activate (or compress) the system, thereby compensating for individual shooting styles of gun mount. This may be done by inserting the 1/8 Allen Key provided through the center hole in the recoil pad, into the head screw, and turning **counter clockwise to increase pressure and clockwise to reduce pressure**. You may start with a ¼ turn. When adjusting the tension it may be somewhat tight to move and squeak a little. This is due to blue lock-tite on the Allen Screw, and is normal. **The tension is set at its strongest point when you receive it.**
- **The system should be cleaned & re-lubed annually.** To do this first remove the comb, then the posts, and the post plate if applicable. Pull back on the recoil pad to remove the slide. The tube mechanism in the stock should be cleaned with a small cleaning rod and patches. **Do NOT use WD-40** type lubricants as they tend to build residue and harden with time. Wipe the slide rods clean and apply a small amount of a **Teflon grease** such as "Synco Super Lube". Reassemble by reversing this process.
- **Access to the stock bolt** is done by removing the system as described above. In addition the end plate must be unscrewed, and the spring and cylinder removed. The cylinder and piston rod have been lubricated during assembly and need no additional lubricant. **Do not use solvent to clean the cylinder and or piston rod.** Reassemble by reversing the order of removal.

You will want to shoot a few practice sessions with this system prior to competition.

Learn not to tense up or grip the gun tightly in anticipation of recoil.

RELAX.....Mount the gun firmly yet GENTLY. Shooting is now going to be fun!

We guarantee both our work and parts for the SoftTouch system for one year.
Any alteration or modification to the system without authorization will void the warranty.